

# The QBOOK

**Qubo Dashcam Pro** 










# **Product**

### Introduction

A smart video camera for your car to record events happening on the road.



- 1. Adhesive Pad
  - 2. Mounting Bracket
- 3. Rotating Shaft6. Mini USB Port

4. Mic

- 5. ON/OFF
- 7. Reboot Key 8. SD Card Slot
- 9. Speaker (at the back)

10. LED (Blue/Red)

# Product Specifications

# & Packaging Contents

Model number : HCA01

Resolution : 1920x 1080P

**Extended Storage:** MicroSD card, upto 256 GB,

Class10 or above

**Wi-Fi**: IEEE 802.11 b/g/n 2.4GHz


**Battery Capacity**: 240 mAh Lithium ion Battery

### **Contents**

- 1. Dashcam with Double-Sided Adhesive Tape
- 2. 3.5 mtr USB Cable
- 3. USB Charger
- 4. Additional Double-Sided Adhesive
- 5. Installation Pry Tool

### Installation

### **Process**



- 1. Charge the Dashcam for 3 hours before Installation. You can use your mobile charger to charge the same.
- 2. Clean the Windshield area where the Dashcam is to be installed.
- 3. Remove the Protective Film from the Double Sided Adhesive and attach it on the windshield such that the view of the Driver is not blocked and proper view of the Front in correct orientation is present.
- 4. Attach the USB Cable with the Dashcam and with the help of Installation Tool/Pry tool you can tuck In the Cable properly by lifting the Windshield/ molding.
- 5. Connect it with the Power Adaptor and insert the adaptor into car 12V charger socket. Please insert SD Card in the SD Card slot for proper installation of the Device. Please use a Class 10 or above SD Card.
- 6. Turn on the Car Ignition and check if the Dashcam gets a Red LED Indication. Device then announces that "Qubo Dashcam is ready for Setup." Download the App and follow further steps from the App.

Note: We recommend to first install the dashcam and then mount it on the Windshield for your convenience.

# **App Download**Instructions

### Step 1

Google Play Store and App Store or you can Scan the below QR Code to download the App-



App Link - https://bit.ly/3Pjsl2n

Step 2.

Install Qubo Pro App



# **To Connect the Dashcam** with the App


Open the App and Choose the Dashcam. Then App will automatically search for available Wi-Fi Hotspots. Choose the one of the Dashcam. It will get auto connected from there. If required, enter the details for the same as follows-

Default Wi-Fi Name: Qubo\_DashCAM\_XXXXXXX

Default Password: 12345678


(Note: During the Installation of the device you will be asked to change your Default Device Wi-Fi Name and Password. Please do so for your device security.)

# **App Screen** Attributes



# **Settings Screen**

### **Attributes**



**Recording Access** 

**Options** 

#### CONTINUOUS RECORDING


To access all the captured recordings, please use the *Timeline Bar* (Marked in red). Green color marks the area which has the stored recordings.

### **EVENT BASED**

The Dashcam creates specific Event based recordings and they can be accessed from the Events tab.

### TRIP BASED

The Dashcam also creates recordings based on Trip and they can be accessed from the Trips tab.



# **LED Indications** and Key Functions

Situation	LED Behavior
Power On	Blue
Commission Starts	Red Blinks
Commission Success	Steady Blue for 5 seconds and off
If commission not initiated from mobile for long time	Red Blinks
Commission Failed	Steady Red
Factory Reset	Blue Blink
Format SD Card	Blue Blink
If user not at all inserted SD card	Steady Red
After power ON, start the recording	Steady Blue

### **REBOOT KEY**

This key reboots the device. Please reboot the device if the Device hangs or functions abnormally.

# **Button**Functionality

### **BUTTON - POWER BUTTON**

Function	Action
Turn the Dashcam On	Press Once
Turn the Dashcam Off	Press Twice
Factory Reset	Long Press & Hold for 10 sec till the LED stops blinking
SD Card Format	If the SD Card is unsupported then a voice prompt is received from Device. Then Press Once to Format SD Card

# Safety

### Precautions

- 1. Qubo Smart Dashcam Pro records videos of outside moving vehicles. It can't protect drivers and passengers from any accidents. We shall not take any responsibility if the user gets involved in any traffic accident and/or bear any loss due to product failure, information loss, or product operation.
- 2. Due to differences in vehicle type, driving preferences, the environment, and other differences, parts of the product or the whole product may not work normally in some circumstances. The device may not record normally due to loss of power source, abnormal temperatures and/or humidity, collisions, damage to the Micro SD card, and other reasons. We do not guarantee that all the recorded videos will be saved completely in any given situation. The images recorded by this product are for reference only.
- 3. Install the product correctly. Do not block the driver's vision. Do not obstruct the air bag. Keep the product at least 20cm away from the driver and passengers. Incorrect installation of the product may cause product failure and injury.
- 4. Keep this product away from strong magnetic fields to avoid damage.
- 5. Do not insert or pull out the Micro SD card when the product is working to avoid damaging the Micro SD card.
- 6. Use a Micro SD card with storage capacity between 16GB and 256GB, and reading and writing speed not lower than Class10. Format the Micro SD card before using it.
- 7. Micro SD card may be damaged after repetitive use. Replace Micro SD cards in time to maintain proper recording.

We shall not bear any responsibility caused by failed Micro SD cards.

- 8. The product can record and save footage of traffic accidents, but we do not guarantee all accident footage can be recorded and saved.
- 9. Do not use this product in temperatures higher than  $65^{\rm o}\,{\rm C}$  or lower than -5° C.

- 10. Do not shake or press the product. Strong impact or shaking may cause irreparable damage to the product.
- 11. Do not clean this product by chemical solvents or cleansers.
- 12. Use this product within the scope of the law.
- 13. Avoid chemical cleansers and solvent that can damage plastic components You should clean the camera lens regularly to improve the quality of recorded video. Wipe the lens with a non-scratch lens cloth, optionally dampened with isopropyl alcohol. Allow the lens to air dry.

# **Troubleshooting**

### My camera feels warm while it is operating.

It is normal for the camera to feel warm during typical use, especially while it is recording high-resolution video or transmitting a Wi-Fi signal.

#### My memory card has degraded and needs to be replaced

All micro SD memory cards wear out after they are overwritten a large number of times. Periodically formatting the card can extend the useful life and improve performance. Because the Qubo Dashcam Pro records continuously, you may need to replace the memory card periodically. Your device detects memory card errors automatically and alerts you when it is time to format or replace your memory card.

You can take these actions to help extend the useful life of the memory card

- · Format the memory card at least one time every six months
- If the device displays a memory card error alert, first try formatting the memory card and then, if necessary, replace the memory card
- Turn off the device when your vehicle is not in use
- If your device is not connected to an ignition- switched vehicle power outlet, you should turn off the device when your vehicle is not in use to prevent the Qubo Dashcam Pro from recording unneeded footage. Transfer saved video footage to a computer. The memory card lasts longer when more free space is available on the card
- Use a memory card with a higher storage capacity
- Because higher-capacity memory cards are overwritten less frequently, they usually last longer

- Use a high-quality memory card with a speed rating of class 10 or higher
- Purchase your replacement memory card from a high-quality manufacturer and a reputable yendor

#### My video recordings are blurry

- Clean the camera lens
- Clean the windshield in front of the camera
- Verify the area of the windshield in front of the camera is cleared by the windshield wipers, and move the device, if necessary

#### My video recordings are choppy or incomplete


- For the best camera and video results, use a high- quality memory card with a speed rating of class 10 or higher. A slower memory card may not record video quickly enough
- If you are viewing videos on your smartphone using a wireless connection to the camera, try viewing them in another location with less wireless interference, or try transferring videos to the smartphone
- Transfer important recordings to a computer or smartphone, and format the memory card
- If the device displays a memory card error alert, first try formatting the memory card and then, if necessary, replace the memory card
- Update your device to the latest software

### My Dashcam does not connect with the App when my phone is connected with Wireless Apple Car Play/ Android Auto

Wireless Apple Car Play/ Android Auto also connect to your phone through a wifi hotspot. Hence, please disconnect them temporarily while connecting your phone to dashcam to set up or view/ download videos from the dashcam. Please note that your dashcam records when the car's ignition is on even if your phone is not connected to the dashcam.

### Parking Mode feature is not working

For Parking Mode feature to work you will need a separate Hardwiring Kit which will be connected with the Fuse Box of the Car. You can purchase it separately from the market.



### LIMITED WARRANTY

### Statement

Thank you for selecting the Qubo Dashcam PRO by Hero Electronix.

**NOTE:** This is a simplified and concatenated version of the standard warranty terms and conditions. For the complete warranty terms and conditions, please refer to the website link given at the end of the document. Alternatively, you can reach out to our toll free helpline number to know about the same.

IMPORTANT: Please retain your receipt as proof of purchase.
HERO Electronix Private Limited warrants to the owner of the Qubo Dashcam Pro, (henceforth referred as Device) that the Device will be free of defects in material and workmanship for a period as mentioned below.

Item	Warranty Period	Scope of Warranty
Device	1 year from the date of Purchase	This warranty covers only the defects in products arising from manufacturing or faulty workmanship.
Car Charger / Cables	6 months from the date of Purchase	
Hardwiring Kit (If Applicable)	6 months from the date of Purchase	
RTC Battery	6 months from the date of Purchase	

During this warranty period, if any defect arises in the Device, HERO Electronix will, at its sole discretion, either

(i) repair the device free of cost with either new or refurbished parts, or (ii) replace the Device with a new or refurbished Device that is equivalent to the Device to be replaced. This limited warranty applies to any repair, replacement part or replacement device for the remainder of the original warranty period or for 90 (Ninety) days, whichever period is longer.

This limited warranty is non-transferable. This limited warranty is only valid in India.

### **Instructions**

For specific instructions about how to obtain warranty services for your Device, please contact our toll-free helpline. In general, you will need to deliver the Device in either its original packing or in equally protective packing to the address specified by Customer Service. HERO Electronix will bear all the cost of the return shipping to the owner except with respect to any Ineligible Product (defined below), for which owner will have to bear all the cost.

# THIS LIMITED WARRANTY DOES NOT COVER THE FOLLOWING (COLLECTIVELY INELIGIBLE PRODUCTS)

- (i) If the warranty seal on the Device is broken.
- (ii) Devices that have been subjected to: (a) modifications, alterations, tampering or improper maintenance and repair (b) handling, storage, installation, testing or use not in accordance with any User guide, Placement guidelines, other instructions provided by HERO Electronix (c) abuse or misuse of the product. (d) breakdown, fluctuations, or interruptions in electrical power or the telecommunication network; or (e) Acts of God, including but not limited to lighting, flood, tornado, earthquake or hurricane.
- (iii) errors and damages caused by: (a) liquid ingress, or spilled food, or physical abuse, or normal wear and tear, (b) use of or being connected to any accessory which was not supplied or authorised by HERO Electronix.
- (iv) Plastic components like front or back covers plus rubber components.
- (v) Physical or cosmetic damage to Silicon cover

#### CORRECT DISPOSAL OF THE PRODUCT



In case you need to dispose of this device at any time in the future, please contact our toll-free helpline. To facilitate effective utilisation of resources, we will arrange the disposal of this device as per the prevailing laws. Please note that electrical products should not be disposed of with household waste.

# FOR ALL PRODUCT RELATED COMPLAINTS/ASSISTANCE, PLEASE CONTACT

Hero Electronix Pvt. Ltd. 503, 5th Floor Rectangle 1, D4, Saket District Center, New Delhi - 110017

Email us at: support@quboworld.com | 1800-572-5757 www.quboworld.com